


B R I G H T E C H

The 3 Ring RGB Floor Lamp

ASSEMBLY



1. Screw the bottom pole (part B) into the base (part A). Then screw together poles C & B and poles D & C, as pictured.
2. Thread the AC wire which extends from the head (part F) through the hollow pole (part E). Screw together the head and hollow pole.
3. To plug the cord into the next uppermost pole (part D): There are 4 protruding prongs within the power pole piece which correspond to the 4 holes on the lamp head's cord. Carefully align the prongs with the holes. Once aligned, they may be pushed together until fully connected. DO NOT attempt to twist, screw, or force connection as this may cause permanent damage to and failure of the lamp.
4. Screw together poles E and D.
5. Plug the lamp into the power adapter cord (part G), and plug the cord into a 110v outlet. Review reverse side of this page for important warnings and safety information prior to use.

OPERATION & USE

This RGB floor lamp is controlled via a three-step foot pedal switch located on the power supply cord.

Powering on and off switches through the modes in this order:

Mode 1 — RGB color changing gradient mode

Mode 2 — Fixed color mode, based on where the gradient was turned off in Mode 1.

Mode 3 — Cool white mode

Please note, the lamp is not dimmable and is not compatible with smart plugs, timers, or wall switches at this time.

BRIGHTECH

SAFETY & WARNINGS

This product is intended for 110v voltage only. Use with a higher voltage is likely to cause damage.

Do not bring this product or any of its components in contact with any water or extreme heat.

Keep between 23 degrees F – 104 degrees F, and below a humidity of 95%.

Do not use this product outside of its intended and advertised use. Do not tamper with internal parts or wiring.

Brightech is not responsible for modifications to this product or any of its electrical components, or for use with externally purchased parts not manufactured to come with this product.

FURTHER RESOURCES | Diagnosis

Thanks to our great track-record with these lights, reported problems have been few and far in-between. But we know, sometimes things can happen. If your product is experiencing any abnormalities, please see below for some more insight as to what may be happening & if there's anything you can do to trouble-shoot.

Note: Never make any temporary or permanent alterations to any parts or components of this product.

Physical or Cosmetic Damage: If the damaged portions of the product are among the separate pieces listed on the opposite side of this guide (see: Assembly), these pieces might be able to be replaced. Parts F & E are combined, as are D, C, and B.

Replacing the Lights or Wiring: The LEDs and wiring are built directly in to the head of the lamp for maximum durability and are non-replaceable at this time.

Light Flashing or Strobging: A malfunction of this sort may suggest a problem with the power adapter cord, necessitating a replacement of this cord.

Lights Dim: If the LEDs have dimmed, or the lamp has failed after first not performing at max brightness, this may suggest a failure of the actual LED component, necessitating a replacement of the head.

Color Settings Malfunctioning: If the color settings are not working as described in the "Operation & Use" section, the wiring may be faulty, and poles or head in need of replacement.

SPECIFICATIONS

Wattage | 15 watts

Brightness | 365 lumens

Adapter | Input AC100-240V | Output DC24V/1A

Need More Help?

Find us on the web
www.brightech.com

Connect with us
[@wearebrightech](https://twitter.com/wearebrightech)

For questions or support
www.brightech.com/contact