
BRIGHTECH

The Artemis Table Lamp



ASSEMBLY

1. Remove the socket ring (part C) from the socket and place the shade onto the socket.
2. Screw the socket ring back onto the socket to tighten the shade into place.
3. Screw the bulb into the socket.
4. Plug the cord into a 110v outlet. Review reverse side of this page for important warnings and safety information prior to use.

OPERATION & USE

POWER : The power button is located on the cord of the lamp, in the form of an On/Off switch.

CUSTOMIZING THE BULB : This lamp's controls out of the box are on/off and the 9-watt bulb emits a warm white light at 3000 Kelvin, which is ideal for a host of lighting environments. If desired, this bulb may be swapped out for an LED bulb with an E26 base and no higher in wattage than 60-watts, including a dimming and/or color-changing smart bulb to increase customizability.

SAFETY & WARNINGS

This product uses a polarized plug so one prong is larger than the other. When plugging into an outlet, take care to plug the correct direction to avoid electric shock.

This product is intended for 110v voltage only. Use with a higher voltage is likely to cause damage.

Do not bring this product or any of its components in contact with any water or extreme heat.

Keep between 23 degrees F - 104 degrees F, and below a humidity of 95%.

Do not use this product outside of its intended and advertised use. Do not tamper with internal parts or wiring.

Brightech is not responsible for modifications to this product or any of its electrical components, or for use with externally purchased parts not manufactured to come with this product.

FURTHER RESOURCES | Diagnosis

Thanks to our great track-record with these lights, reported problems have been few and far in-between. But we know, sometimes things can happen. If your product is experiencing any abnormalities, please see below for some more insight as to what may be happening & if there's anything you can do to trouble-shoot.

Note: Never make any temporary or permanent alterations to any parts or components of this product.

Physical or Cosmetic Damage: If the damaged portions of the product are among the separate pieces listed on the opposite side of this guide (see: Assembly), these pieces might be able to be replaced.

Light not Working: If the bulb is not working, the metal tab in the socket might have pushed in too much during production. Try unplugging the lamp and pulling out the tab slightly, to help create a connection between the two. If this doesn't fix the problem, we recommend trying to swap with another bulb. If the new bulb doesn't fix the issue, the lamp might be defective.

SPECIFICATIONS

Bulb Wattage | 9.5 watts
Bulb Sizing | E26 base | A19 shape
Color Temperature | 3000 kelvin
Brightness | 800 lumens
Max Wattage of the Socket | 60 watts

Need More Help?

Find us on the web
www.brightech.com

Connect with us
@wearebrightech

For questions or support
www.brightech.com/contact