
BRIGHTECH

The Gemini Floor Lamp

ASSEMBLY

1. Screw the bottom pole (part B) into the base (part A), taking care to set at a 90 degree angle and that the threading is properly aligned.
2. Screw the subsequent poles into the bottom pole going up, namely the middle pole (part C), then the upper pole (part D), and then the head (part E).
3. Plug the power adapter cord (part G) into the cord of the lamp.
4. Plug the cord into a 110v outlet. Review reverse side of this page for important warnings and safety information prior to use.



OPERATION & USE

POWER & DIMMING : The power button is located on the top of the pole, in the form of a touch sensor. Simply tap the touch sensor to turn on. To dim the lamp or to turn it off, tap the button again. The lamp will first cycle through two dimmer brightness levels, and on the third tap, it will shut off.

USING WITH A WALL SWITCH: To use the lamp with a wall switch, simply plug it into an outlet that is built to be powered by the wall switch. The lamp will be able to be turned on and off via the switch to the brightness that it was on prior to being turned off. Dimming cannot be controlled via light switch and can only be adjusted via the touch sensor on the body of the lamp.

SAFETY & WARNINGS

This product is intended for 110v voltage only. Use with a higher voltage is likely to cause damage.

Do not bring this product or any of its components in contact with any water or extreme heat.

Keep between 23 degrees F - 104 degrees F, and below a humidity of 95%.

Do not use this product outside of its intended and advertised use. Do not tamper with internal parts or wiring.

Brightech is not responsible for modifications to this product or any of its electrical components, or for use with externally purchased parts not manufactured to come with this product.

FURTHER RESOURCES | Diagnosis

Thanks to our great track-record with these lights, reported problems have been few and far in-between. But we know, sometimes things can happen. If your product is experiencing any abnormalities, please see below for some more insight as to what may be happening & if there's anything you can do to trouble-shoot. If the purchase is covered under warranty, notify us of any weaknesses or malfunctions as soon as they are discovered.

Note: Never make any temporary or permanent alterations to any parts or components of this product.

Physical or Cosmetic Damage: If the damaged portions of the product are among the separate pieces listed on the opposite side of this guide, these pieces might be able to be replaced. The main body of the lamp is fully wired together and is considered one piece.

Replacing the Lights or Wiring: The LEDs and wiring are built directly in to the head of the lamp for maximum durability and are non-replaceable at this time.

Light Flashing or Strobing: A malfunction of this sort may suggest a problem with the power adapter cord, necessitating a replacement of this cord.

Lights Dim: If the LEDs have dimmed, or the lamp has failed after first not performing at max brightness, this may suggest a failure of the actual LED component, necessitating a replacement of the head.

Replacing Shades: These shades are crafted specifically for the Gemini and cannot be replaced generically.

SPECIFICATIONS

Wattage | 15 watts
Color Temperature | 3000 kelvin
Brightness | 1300 lumens
Adapter | Input AC100-240V | Output DC24V/1A

Need More Help?

Find us on the web
www.brightech.com

Connect with us
@wearebrightech

For questions or support
www.brightech.com/contact