BRIGHTECH

The Libra Floor Lamp

ASSEMBLY

1. Screw together the upper pole (part C) and the lower pole (part B) taking care to align straight and that the threading connects securely.
2. Screw the lower pole into the base (part A).
3. Plug the lamp into the power adapter cord (part D), and plug the cord into a 110v outlet. Review reverse side of this page for important warnings and safety information prior to use.


OPERATION & USE

POWER : The power is controlled via a foot pedal on the cord of the lamp, and it has three color settings. Simply tap the button to turn on, and tap again to turn off.

COLOR TEMPERATURE SELECTION : To choose color settings, turn the lamp on, then off, and then on again in quick succession. When the lamp turns on the next time, it will rotate to the next color temperature option. Continue the quick tapping to rotate through the options to choose your ideal light type.

DIMMING : To dim the lamp, tap and hold the foot pedal. After about a second, it will begin the stepless dimming cycle. When the light level reaches the lowest available, it will cycle back up to max brightness. To choose a light level, simply let go of the button and it will stop at the level chosen.

USING WITH A WALL SWITCH: To use the lamp with a wall switch, simply plug it into an outlet that is built to be powered by the wall switch. The lamp will be able to be turned on and off via the switch, but the dimming needs to be controlled via the power button on the body of the lamp.



SAFETY & WARNINGS

This product uses a polarized plug so one prong is larger than the other. When plugging into an outlet, take care to plug the correct direction to avoid electric shock.

This product is intended for 110v voltage only. Use with a higher voltage is likely to cause damage.

Do not bring this product or any of its components in contact with any water or extreme heat.

Keep between 23 degrees F - 104 degrees F, and below a humidity of 95%.

Do not use this product outside of its intended and advertised use. Do not tamper with internal parts or wiring.

Brightech is not responsible for modifications to this product or any of its electrical components, or for use with externally purchased parts not manufactured to come with this product.

FURTHER RESOURCES | Diagnosis

Thanks to our great track-record with these lights, reported problems have been few and far in-between. But we know, sometimes things can happen. If your product is experiencing any abnormalities, please see below for some more insight as to what may be happening & if there's anything you can do to trouble-shoot.

Note: Never make any temporary or permanent alterations to any parts or components of this product.

Physical or Cosmetic Damage: If the damaged portions of the product are among the separate pieces listed on the opposite side of this guide (see: Assembly), these pieces might be able to be replaced. The main body of the lamp is fully wired together and is considered one piece.

Replacing the Lights or Wiring: The LEDs and wiring are built directly in to the head of the lamp for maximum durability and are non-replaceable at this time.

Light Flashing or Strobing: A malfunction of this sort may suggest a problem with the power adapter cord, necessitating a replacement of this cord.

Lights Dim: If the LEDs have dimmed, or the lamp has failed after first not performing at max brightness, this may suggest a failure of the actual LED component, necessitating a replacement of the lamp body.

SPECIFICATIONS

Wattage | 14.5 watts

Color Temperature | 3000 kelvin

Brightness | 1100 lumens

Adapter | Input AC100-240V | Output DC24V/1A

Need More Help?

Find us on the web
www.brightech.com

Connect with us
@wearebrightech

For questions or support
www.brightech.com/contact