
Brightech® Logan LED Floor Lamp Assembly Instructions



1. Remove all parts before assembling and place on a flat surface.
   To assemble the shade please check page 2 (shade instructions).

2. Screw pole (C) clockwise into pole (B) to tighten.

3. Screw pole (D) clockwise into pole (C) to tighten.

4. Insert threaded end of pole (B) through hole in base (A), and slip flat washer (I) onto threading on the underside of the base, followed by nut (J). Use wrench (H) to tighten nut, then pull the power cord's slack carefully through the pole.

5. Set shade (F) on the socket and secure the shade by screwing socket ring (G) clockwise onto the socket.

To extend/retract the arc: First, pull the plug out of the outlet. Next, loosen screw (E), feed some of the cord into the base of the lamp, and pull out arc (D2). If arc doesn't extend all the way, feed additional cord into the base, and attempt again. Finally, tighten screw (E). To shorten the arc, loosen screw (E), feed (D2) back into (D1), pull the cord back out from the base, and tighten (E).

IMPORTANT SAFETY INSTRUCTIONS:
This product has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet in only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. DO NOT ALTER THE PLUG.

Max Wattage: 150 watt incandescent or 42 watt CFL equivalent. A 9.5 watt LED bulb is included. (Incandescent/CFL not included)

Extend Your Warranty From 3 Years To 5 Years
To extend your warranty by 2 extra years for a total of 5 years' warranty, register your purchase by filling in the brief form at https://brightech.com/pages/extended-warranty .

Please contact us via our website if you need any help with your new lamp.
www.brightech.com