
BRIGHTECH

The Saturn Table Lamp



ASSEMBLY

1. Screw poles (B) and (C) together, and then screw into the base (A).
2. Gently place the LED rings onto the grooves on the poles. These grooves are essentially the power control for the rings, so care should be taken that the pins be treated delicately.
3. Plug the power adapter cord (E) into the cord of the lamp.
4. Plug the cord into a 110v outlet. Review reverse side of this page for important warnings and safety information prior to use.

OPERATION & USE

POWER & DIMMING : The power button is located at the very top of the lamp's pole, in the form of a touch sensor. Simply tap the sensor to turn on. To dim the lamp or to turn it off, tap the button again. The lamp will first cycle through two dimmer brightness levels, and on the third tap, it will shut off.

REMOVING THE RINGS : The Saturn's rings can safely be rmoved and re-placed on the lamp while the lamp is still turned on. However, extended removal of the rings is not recommended as this will drain power to the lamp even while the rings are not in use.

USING WITH A WALL SWITCH : To use this lamp with a wall switch, simply plug it into an outlet that is built to be powered with the wall switch. The lamp will be able to be turned on and off via the switch to the brightness level that it was on prior to being turned off. Dimming cannot be controlled via light switch and can only be adjusted via the controls witin the lamp itself.

SAFETY & WARNINGS

This product is intended for 110v voltage only. Use with a higher voltage is likely to cause damage to the product as well as the electrical component it is being powered by.

Do not bring this product or any of its components in contact with any water or extreme heat.

Keep between 23 degrees F & 104 degrees F, and below a humidity of 95%.

Do not use this product outside of its intended and advertised use. Do not tamper with internal parts or wiring.

Brightech is not responsible for any failures associated with modifications to this product or any of its electrical components, or when the product is used with externally purchased parts not manufactured to come with this product.

FURTHER RESOURCES | Diagnosis

Though all of our products pass rigorous pre-production quality control, we understand that sometimes things can happen. If your product is experiencing any abnormalities, please see below fo some more insight as to what may be happening & if there's anything you can do to troubleshoot. If the purchase is covered under warranty, notify us of any weaknesses or malfunctions as soon as they are discovered.
Note: Never make any temporary or permanent alterations to any parts or components of this product.

Physical or Cosmetic Damage: If the damaged portions of the product are among the separate pieces listed on the opposite side of this guide (see: Assembly), these pieces might be able to be replaced. However any parts that are connected to other parts by wiring are considered one full piece as a unit.

Light Flashing or Strobing: A malfunction of this sort may suggest a problem with the power adapter cord, necessitating a replacement of the cord.

Lights are Dim: If the LEDs have dimmed, or the lamp has failed after first not performing at max brightness, this may suggest a failure of the actual LED component, necessitating a replacement of the head.

Single-Ring Malfunction: If a single ring is causing issues with the entire lamp's function, a ring replacement should fix this.

SPECIFICATIONS

Wattage | 10 watts
Color Temperature | 3000 kelvin
Brightness | 865 lumens
Adapter | 24v, 0.5A

Need More Help?

Find us on the web
www.brightech.com

Connect with us
@wearebrightech

For questions or support
www.brightech.com/contact