BRIGHTECH

The Libra Table Lamp



ASSEMBLY

1. Plug the lamp into the power adapter cord (part B).
2. Plug the cord into a working 110v outlet. Review reverse side of this page for important warnings and safety information prior to use.

OPERATION & USE

POWER : The power is controlled via a touch sensor located right on the base of the lamp, and it has three color settings. Simply tap the button to turn on, and tap again to turn off.

COLOR TEMPERATURE SELECTION : To choose color settings, turn the lamp on, then off, and then on again in quick succession. When the lamp turns on the next time, it will rotate to the next color temperature option. Continue the quick tapping to rotate through the options and to choose your ideal light type.

DIMMING : To dim the lamp, tap and hold the touch sensor. After about a second, it will begin the stepless dimming cycle. When the light level reaches the lowest available, it will cycle back up to max brightness. To choose a light level, simply let go of the button and it will stop at the level chosen.

USING WITH A WALL SWITCH: To use the lamp with a wall switch, simply plug it into an outlet that is built to be powered by the wall switch. The lamp will be able to be turned on and off via the switch to the color choice and brightness that it was on prior to being turned off. Dimming cannot be controlled via light switch and can only be adjusted via the touch sensor on the body of the lamp.

SAFETY & WARNINGS

This product is intended for 110v voltage only. Use with a higher voltage is likely to cause damage.

Do not bring this product or any of its components in contact with any water or extreme heat.

Keep between 23 degrees F - 104 degrees F, and below a humidity of 95%.

Do not use this product outside of its intended and advertised use. Do not tamper with internal parts or wiring.

Brightech is not responsible for modifications to this product or any of its electrical components, or for use with externally purchased parts not manufactured to come with this product.

FURTHER RESOURCES | Diagnosis

Thanks to our great track-record with these lights, reported problems have been few and far in-between. But we know, sometimes things can happen. If your product is experiencing any abnormalities, please see below for some more insight as to what may be happening & if there's anything you can do to trouble-shoot. If the purchase is covered under warranty, notify us of any weaknesses or malfunctions as soon as they are discovered.

Note: Never make any temporary or permanent alterations to any parts or components of this product.

Physical or Cosmetic Damage: If the damaged portions of the product are among the separate pieces listed on the opposite side of this guide (see: Assembly), these pieces might be able to be replaced. The main body of the lamp is fully wired together and is considered one piece.

Replacing the Lights or Wiring: The LEDs and wiring are built directly in to the head of the lamp for maximum durability and are non-replaceable at this time.

Light Flashing or Strobing: A malfunction of this sort may suggest a problem with the power adapter cord, necessitating a replacement of this cord.

Lights Dim: If the LEDs have dimmed, or the lamp has failed after first not performing at max brightness, this may suggest a failure of the actual LED component, necessitating a re-placement of the lamp body.

SPECIFICATIONS

Wattage | 9.5 watts
Color Temperature | 3000/4000/6000 kelvin
Brightness | 500 lumens
Adapter | Input AC100-240V | Output DC24V/1A

Need More Help?

Find us on the web
www.brightech.com

Connect with us
@wearebrightech

For questions or support
www.brightech.com/contact